



Especificações Técnicas

L350
EAI(Latin 120V),,U-PS

L350
EAI(Latin 220V),,U-PS

L300
EAI(Latin) UC,,U-PS

L300
EAI(Latin) AR,,U-PS

L210
EAI(Latin 120V),,U-PS

L210
EAI(Latin Brazil UPS),,U-PS

L210
EAI(Latin 220V),,U-PS

EAI(Latin 220V),,U-PS
L110
EAI(Latin 120V),,U-PS

L110
EAI(Latin Brazil UPS),,U-PS

L110
EAI(Latin 220V),,U-PS

L355
EAI(Latin 120V),,U-PS

L355
EAI(Latin Brazil UPS),,U-PS

L355
EAI(Latin 220V),,U-PS

L120
EAI(Latin 120V),,U-PS

L120
EAI(Latin 220V),,U-PS

L455
EAI(Latin) UC,,U-PS

L455
EAI(Latin) BR,,U-PS

L455
EAI(Latin) AR,,U-PS

L365
EAI(Latin) UC,,U-PS

L365
EAI(Latin) BR,,U-PS

L365
EAI(Latin) AR,,U-PS

L220
EAI(Latin) UC,,U-PS

L220
EAI(Latin) BR,,U-PS

L220
EAI(Latin) AR,,U-PS

L310
EAI(Latin) UC,,U-PS

L310
EAI(Latin) AR,,U-PS

ET-2550
EAI(NA),,U-PS

L475
EAI(Latin) UC,,U-PS

L475
EAI(Latin) BR,,U-PS

L475
EAI(Latin) AR,,U-PS

ET-2500
EAI(N/A),,U-PS

L375
EAI(Latin)UC,,U-PS

L375
EAI(Latin) BR,,U-PS

L375
EAI(Latin) AR,,U-PS

L380
EAI(Latin) UC,,U-PS

L380
EAI(Latin) BR,,U-PS

L380
EAI(Latin) AR,,U-PS

ET-2600
EAI(NA),,

L395
EAI(Latin) UC,,

L395
EAI(Latin) BR,,

L395
EAI(Latin) AR,,

ET-2650
EAI(NA),,U-PS

L495
EAI(Latin) UC,,

EAI(Latin) UC,,
L495
EAI(Latin) BR,,

L495
EAI(Latin) AR,,

L396
EAI(Latin) UC,,U-PS

L396
EAI(Latin) BR,,U-PS

XP-2101
EAI(Latin) UC,,U-PS

XP-2101
EAI(Latin) AR,,U-PS

Garantía:

Garantía de 90 días